



SIMPSON HOLDOWN SCHEDULE							
HOLDOWN	POST SIZE (MIN.)	1/4 X 2 1/2" SDS SCREWS	ANCHOR ROD	WASHER PLATE IN CONC.	CAPACITY	25% REDUCTION	
HDU2	4 X 4	6	5/8" # A307	3" SQ. X 1/2"	2445	1834	
HDU4	4 X 4	10	5/8" # A307	3" SQ. X 1/2"	3485	2614	
HDU5	4 X 4	14	5/8" # A307	3" SQ. X 1/2"	3960	2970	
HDU8	6 X 6	20	7/8" # A307	3" SQ. X 1/2"	6945	5209	
HDU11	6 X 6 OR 4 X 8	30	1" # A307	3" SQ. X 1/2"	8315	6237	
HDU14	6 X 6 OR 4 X 8	36	1" # A307	3" SQ. X 1/2"	9850	7388	
HD19	6 X 8	5-1" # BOLTS	1 1/4" # A307	3" SQ. X 1/2"	16270	12203	

LARR 25720 - SIMPSON HDU LARR 25828 - SIMPSON HD

SHEAR WALL SCHEDULE							
A USE 15/32" 5-PLY PLYWOOD STRUCT'L I, BLOCKED ALL EDGES 10d COMMON NAILS: EDGES @ 4" O.C. INTERM @ 12" O.C. PLATE TO BLOCKING: 2-1/4" # LAG SCREWS @ EA. BLKG. (8" O.C. MAX.) BLOCKING TO PLATE: 1-3/4" # LAG SCREWS @ 8" O.C. 5/8" # A.B. @ 32" AT FOUNDATION SILL PLATE. NAIL TO BE 1/2" FROM PANEL EDGES. ALLOWABLE SHEAR V = 340 #/I							
B USE 15/32" 5-PLY PLYWOOD STRUCT'L I, BLOCKED ALL EDGES 10d COMMON NAILS: EDGES @ 4" O.C. INTERM @ 12" O.C. PLATE TO BLOCKING: 2-1/4" # LAG SCREWS @ EA. BLKG. (8" O.C. MAX.) BLOCKING TO PLATE: 1-3/4" # LAG SCREWS @ 8" O.C. 5/8" # A.B. @ 32" AT FOUNDATION SILL PLATE. NAIL TO BE 1/2" FROM PANEL EDGES. ALLOWABLE SHEAR V = 340 #/I							
C USE 15/32" 5-PLY PLYWOOD STRUCT'L I, BLOCKED ALL EDGES 10d COMMON NAILS: EDGES @ 4" O.C. INTERM @ 12" O.C. PLATE TO BLOCKING: 2-1/4" # LAG SCREWS @ EA. BLKG. (8" O.C. MAX.) BLOCKING TO PLATE: 1-3/4" # LAG SCREWS @ 8" O.C. 5/8" # A.B. @ 32" AT FOUNDATION SILL PLATE. NAIL TO BE 1/2" FROM PANEL EDGES. ALLOWABLE SHEAR V = 340 #/I							
D USE 15/32" 5-PLY PLYWOOD STRUCT'L I, BLOCKED ALL EDGES 10d COMMON NAILS: EDGES @ 4" O.C. INTERM @ 12" O.C. PLATE TO BLOCKING: 2-1/4" # LAG SCREWS @ EA. BLKG. (8" O.C. MAX.) BLOCKING TO PLATE: 1-3/4" # LAG SCREWS @ 8" O.C. 5/8" # A.B. @ 32" AT FOUNDATION SILL PLATE. NAIL TO BE 1/2" FROM PANEL EDGES. ALLOWABLE SHEAR V = 340 #/I							

